idealair group

ONEAIR

METAL

High induction quarter round duct system

Installation Instructions

DHI

INDEX

General information

- Delivery and reception p. 1
- Washing and maintenance instructions p. 2
- Identification of the sections p. 2

Assembly systems

1. Installation by ceiling rail p. 3
    1.1 Installation procedure p. 4
    1.2 Installation recommendations p. 4
2. Installation by wire p. 5
    2.1 Installation procedure p. 6
    2.2 Installation recommendations p. 6
3. Tips for use p. 7

ONEAIR DHI TEXTILE

As part of our ongoing program of product development and improvement, Idealair Group reserves the right to make changes in design or specification to products without notice or obligation and to change or discontinue models.

GENERAL INFORMATIONS

On the following pages you will find assembly and installation instructions for the **ONEAIR DHI TEXTILE QUARTER ROUND** diffusers.

DELIVERY AND RECEPTION

Before proceeding with the installation, the customer is invited to check the condition of the goods received and all correspondence with the delivery note.

We ask you to indicate the presence of any damaged parts at the time of receipt of the goods and, if applicable, to indicate in the carrier's delivery note the acceptance subject to reservation, specifying exactly the type of damage found.

In addition, please contact us as soon as possible at amministrazione@oneair.it and, if possible, send us photos of the damaged parts.



As part of our ongoing program of product development and improvement, Idealair Group reserves the right to make changes in design or specification to products without notice or obligation and to change or discontinue models.

WASHING AND MAINTENANCE INSTRUCTIONS

For standard or B s1 d0 class fabric duct:

- Use neutral powder or liquid detergent
- The water temperature must not exceed 30° C and the washing machine load must be moderate; although the fabric resists higher temperatures, excessive heat combined with the mechanical action of the washing machine could ruin the internal resin finish.
- Dry at room temperature by hanging the textile diffusers wet or at most after a light spin in the spin cycle not exceeding 500 rpm

For A1 class fabric duct :

- This type of fabric is very delicate and it is recommended to be treated by expert operators to avoid breakage or rapid wear of the material. During the assembly phase of the duct there may be some fiberglass filaments due to the processing. These can cause irritation to the eyes or skin, therefore we recommend the use of protective systems.
- Washing must be done by hand with neutral soap by immersing the product in large tanks that allow the channel not to undergo too many creases/wrinkles.

For all types of fabric:

After washing the duct can be used by completing the drying with the operation otherwise dry them thoroughly before storing them in a dry environment.

Upon request, we provide a washing service for textile ducts.

IDENTIFICATION OF THE SECTIONS

On each duct there is a label showing nomenclature and order number. For their identification, refer to the technical drawings approved in the order confirmation, a copy of which is sent with the purchased material.



Code label

As part of our ongoing program of product development and improvement, Idealair Group reserves the right to make changes in design or specification to products without notice or obligation and to change or discontinue models.

ASSEMBLY SYSTEMS

1. INSTALLATION BY CEILING RAIL

These installation systems include a kit consisting of:

- Rib (**A**) sewn on the duct
- Aluminum rail (**B**)
- Metal (**C**) or fabric (**D**) hose clamp according to the diameter complete with ratchet for tightening the duct entrance on the rigid mouthpiece prepared on site

ATTENZIONE: tappi a pressione e viti per il fissaggio non sono forniti.



Double rail with rib

As part of our ongoing program of product development and improvement, Idealair Group reserves the right to make changes in design or specification to products without notice or obligation and to change or discontinue models.

1.1 INSTALLATION PROCEDURE

1. Fix the aluminum rails to the ceiling by drilling the same and then inserting appropriate pressure caps (not supplied), paying attention to their alignment.
2. Carefully chamfer the ends of the rails to avoid damaging the fabric during installation.
3. Insert the ribs into their respective rails by sliding them along their entire length and helping to insert them at the end. If you feel abnormal resistance, remove the duct and check the rails at the junction points between one bar and another.
4. Repeat step 3 until all the ducting is completely installed, joining the various sections of duct with the hinges at the ends.
5. Fit the textile diffuser on the metal mouthpiece and fix it using the tensioning ratchet with hose clamp.

1.2 INSTALLATION RECOMMENDATIONS

On completion of installation, also check:

• The integrity and stability of the wall supports and the correct fixing of the aluminum rail

• The tightness of the duct on the rigid inlet, in particular of having tightened the hose clamp well

• The correct tightening of all the hinges that join the various sections of the duct

As part of our ongoing program of product development and improvement, Idealair Group reserves the right to make changes in design or specification to products without notice or obligation and to change or discontinue models.

2. INSTALLATION BY WIRE

These installation systems include a kit consisting of:

- Hooks with carabiner (**A**) sewn on the duct
- Metal wire (**B**) of suitable length
- Clamps (**C**) for fixing the wire to turnbuckles and anchors
- Turnbuckles (**D**) to adjust the tension of the metal wire
- Metal (**E**) or fabric (**F**) hose clamp according to the diameter complete with ratchet for tightening the duct entrance on the rigid mouthpiece prepared on site.

ATTENTION: pressure caps and hooks for fixing to the wall are not supplied.





Double wire

As part of our ongoing program of product development and improvement, Idealair Group reserves the right to make changes in design or specification to products without notice or obligation and to change or discontinue models.

2.1 INSTALLATION PROCEDURE

1. Fix a hook to a wall using pressure caps or sturdy ceiling brackets (not supplied) then follow the sections indicated on the executive drawings to know the position of wire or rails
2. Mount the metal cable by applying the clamps and turnbuckles included in the supply to the ends
3. Tighten the cables well by screwing the tensioners
4. Hook the clips to the cables
5. Repeat point 4) until all the ducting is completely installed, joining the various sections of duct with the hinges at the ends
6. Fit the fabric duct on the metal mouthpiece and secure it using the hose clamp included in the supply
7. Extend the duct to its full length and slowly start the fan
8. If necessary, for ducts with long sections, anchor the cable to the ceiling with intermediate hangings every 5 m approximately, making sure that these do not create an obstacle to the positioning of the carabiners and leaving the duct free to move.



RIGHT

WRONG

2.2 INSTALLATION RECOMMENDATIONS

Some advices for the proper functioning of the fabric ducts:

• Provide for the gradual start-up of the fan (for example with slow opening damper or inverter) to prevent the ducts from swelling with a violent blow that could cause tearing

• Provide flow straightening fins in the outlets that feed the fabric ducts to reduce air turbulence at the entrance

• Shape the mouthpieces on which the fabric ducts are fitted so that they cannot come off

• Smooth the edges of these mouthpieces to prevent the fabric from wearing and cutting

As part of our ongoing program of product development and improvement, Idealair Group reserves the right to make changes in design or specification to products without notice or obligation and to change or discontinue models.

3. TIPS FOR USE

Some simple measures to increase the efficiency of the implant and the duration of the tissue ducts:

• Provide for the gradual start-up of the fan (for example with slow opening damper or inverter) to avoid the "water hammer" effect during the inflation phase which could cause tearing or premature wear.

• Provide flow straightening fins in the outlets that feed the fabric ducts to reduce air turbulence at the entrance

• Shape the mouthpieces on which the fabric ducts are fitted so that they cannot come off

• Smooth the edges of these mouthpieces to prevent the fabric from wearing and cutting

For the installation of the double wire or the double rail, refer to the detailed measurements of the technical drawing supplied together with the order confirmation.

As part of our ongoing program of product development and improvement, Idealair Group reserves the right to make changes in design or specification to products without notice or obligation and to change or discontinue models.

idealair group

Head Office
Alexandria NSW
Sydney Corporate Park
Unit 1, Building 1,
85 O'Riordan Street
Alexandria NSW 2015
T > *+61 (02) 8073 3310*
Fax > *(02) 8073 3320*

Acacia Ridge QLD
1C, 29-41 Lysaght Street
Acacia Ridge QLD 4110
T > *+61 (07) 3063 0300*
Fax > *(07) 3063 0309*

Fyshwick ACT
53 Tennant Street,
Fyshwick, ACT, 2609
T > *+61 (02) 6280 5511*
Fax > *(02) 6280 6953*

Dandenong South VIC
63 Vision Street,
Dandenong South, VIC 3175
T > *+61 (03) 9696 3044*
Fax > *(03) 9696 0188*

Hobart TAS
2/10 Lampton Avenue
Derwent Park, TAS, 7009
T > *+61 (03) 6273 6455*
Fax > *(03) 6273 5924*

E > *info@idealairgroup.com.au*
W > *idealairgroup.com.au*

E > *info@majorair.com.au*
W > *idealairgroup.com.au*

As part of our ongoing program of product development and improvement, Idealair Group reserves the right to make changes in design or specification to products without notice or obligation and to change or discontinue models.